

| TRUCK # | YEAR | MILES  | HOURS     | DATE       | WORK PERFORMED                                        |
|---------|------|--------|-----------|------------|-------------------------------------------------------|
| 17      | 2000 |        |           |            |                                                       |
|         |      | 4030   |           | 1/18/2001  | Service                                               |
| 17      |      | 8970   |           | 05 21 01   | Service                                               |
| 17      |      | 13994  |           | 08 25 01   | Service                                               |
| 17      |      | 19153  |           | 12 12 01   | Service                                               |
| 17      |      | 30231  |           | 07 18 02   | Service                                               |
| 17      |      | 34732  |           | 12 11 02   | Replace pto gear in trans service air fuel            |
| 17      |      | 42219  |           | 06 26 03   | Service air fuel                                      |
| 17      |      | 49998  |           | 01 27 04   | Service                                               |
| 17      |      | 54739  |           | 06 14 04   | Valve stuck in valve body,replace valve               |
|         |      |        |           |            | body, filter & fluid                                  |
| 17      |      | 62619  |           | 11 29 04   | Repair leak inside of turret &service                 |
|         |      |        |           |            | Air & fuel filter                                     |
| 17      |      | 63212  |           | 01 05 05   | Replace check valve in control                        |
| 17      |      | 67334  |           | 04 20 05   | Replace high pressure injection pump                  |
|         |      |        |           |            | line service                                          |
| 17      |      | 70429  |           | 6/14/2005  | Replace expansion valve , receiver dryer,             |
|         |      |        |           |            | evacuate , & charge system                            |
| 17      |      | 73804  | storm mis | 9/6/2005   | Service , Adjust brakes                               |
| 17      |      | 75867  |           | 9/27/2005  | Replace Batteries                                     |
| 17      |      | 76418  |           | 10/10/2005 | Remove Heater Core & AC Evaperator                    |
|         |      |        |           |            | Clean Out Bugs Weld Rear Step                         |
| 17      |      | 79614  |           | 01 03 06   | Replace Hydraulic Return Filter &                     |
|         |      |        |           |            | Adaptor Housing                                       |
| 17      |      | 80021  |           | 01 13 06   | Replace Hydraulic Hose End On                         |
|         |      |        |           |            | Leveling Cylinder At Bucket                           |
| 17      |      | 84094  |           | 04 06 06   | Replace steer tires & both spot lights                |
| 17      |      | 84622  |           | 04 18 06   | Service, replace purge valve in air dryer             |
|         |      |        |           |            | replace fuel & air filters & water/fuel seprator      |
| 17      |      | 85437  |           | 05 02 06   | Replace signal light switch                           |
| 17      |      | 89475  |           | 07 10 06   | Replace left hood latch pin on fender                 |
| 17      |      | 92386  |           | 08 23 06   | Repair 2 - speed throttle                             |
| 17      |      | 95177  |           | 10 31 06   | Service, replace fuel filter, air filter, water/ fuel |
|         |      |        |           |            | seperator, air check valve, left front brake          |
|         |      |        |           |            | chamber                                               |
| 17      |      | 95567  |           | 11 06 06   | Replace drive tires                                   |
| 17      |      | 96840  |           | 12 02 06   | Replace left & right front brake hose                 |
| 17      |      | 198018 | 6907      | 01 09 15   | Repair and adjust spot light on hood                  |
| 17      |      | 199890 | 7061      | 5/22/2015  | replace primer pump for hard start                    |
| 17      |      | 200481 | 7102      | 06 25 15   | Repair bucket tool holder, bin doors, and             |
|         |      |        |           |            | work light wiring.                                    |
| 17      |      | 204838 | 7378      | 11 05 15   | Dot inspection                                        |