

Service Invoice - Summary

BILL TO:

MAINTENANCE

Model

Serial # FJX12582

Equipment #:

Machine ID #:

Meter Reading 135.0

PAGE

1 of 9

DESCRIPTION

TOTAL

TR BRACKET IS BENT AND SHIMS WORN OUT ON THUMB,
01 INSPECT MACHINE
02 TROUBLESHOOT THUMB
03 PERFORM PM 4
04 TROUBLESHOOT QUICK COUPLER
07 REMOVE & INSTALL PRIMARY AIR FILTER
08 REMOVE & INSTALL CAB AIR FILTER
09 REMOVE & INSTALL WINDOW WIPER
10 REMOVE & INSTALL PROTECTIVE COVERING
11 REMOVE & INSTALL LIGHT(S)
12 REMOVE & INSTALL CHECK VALVE
13 TEST/CHECK & ADJUST V-BELT(S)
15 REMOVE & INSTALL QUICK COUPLER
16 TEST/CHECK & ADJUST HOSES & LINES
17 REMOVE & INSTALL UNIT INJECTOR
18 REMOVE & INSTALL QUICK COUPLER
98 PROG AS RECONDITION MACHINE

12,535.02

Model #
Model #
Serial #

Equipment #:
Machine ID #:
Meter Reading

PAGE
1 of 9

DESCRIPTION

TOTAL

TR BRACKET IS BENT AND SHIMS WORN OUT ON THUMB,
01 INSPECT MACHINE
02 TROUBLESHOOT THUMB
03 PERFORM PM 4
04 TROUBLESHOOT QUICK COUPLER
07 REMOVE & INSTALL PRIMARY AIR FILTER
08 REMOVE & INSTALL CAB AIR FILTER
09 REMOVE & INSTALL WINDOW WIPER
10 REMOVE & INSTALL PROTECTIVE COVERING
11 REMOVE & INSTALL LIGHT(S)
12 REMOVE & INSTALL CHECK VALVE
13 TEST/CHECK & ADJUST V-BELT(S)